


Remote Installation Kit for Pulsarlube OL

Kit No. C046~C047

DETAILED PARTS AND ASSEMBLY PROCEDURE



LIST	PART No.	DESCRIPTION	Q'TY
1	B051	Self Drilling Screw, #8 x 19, Steel	4
2	B003-01	Oil Brush Bracket, "L" Shape, Steel	2
3	A315	Reducer, PT3/8" F x PF1/4" Mx30mm x PT1/8" F, Steel	1
4	B058	Tooth Washer, O.D.23mm x I.D.14.5mm x 1t, Steel	2
5	N001	Nut, PF1/4" F x 5mm, Steel	2
6	A317	One-Touch fitting, Ø4 x PT1/8" M, Nickel Plated	2
7	C021-1	Nylon Tube, 3m (10ft) O.D. 4mm × I.D. 2.5mm	1
8	A316	Reducer, PT1/8" F x PF1/4" M x 25mm Adaptor, Steel	1
9	C017	Oil Brush, 45 x 20 x 30mm Flat Nylon, PF1/4" F	1
10	C018	Oil Brush, 74 x 20 x 30mm Flat Nylon, PF1/4" F	1

ASSEMBLY PROCEDURE

- 1. Install the Oil Brush Bracket (②) in an appropriate location using the Self Drilling screws (①).
- 2. Fasten the Reducer (3), Tooth washer (4), Nut (5) and One-Touch fitting (6).
- 3. Install another Oil Brush Bracket (2) in an appropriate location using the Self Drilling screw (1) to remote install.
- 4. Fasten the Tooth washer (4), Nut (6), Reducer (3) andOne-Touch fitting (6). Connect each end of the Nylon Tube (7) to bothOne-Touch fittings (6).
- 5. Connect the appropriate brush ((9)) or ((10)) to the thread of the Reducer ((8)).

COMMENTS

Output volume may vary depending on oil viscosity, ambient temperature, etc.

LIST & PART No.	KIT No.	DESCRIPTION
[1 ~ 8] + 9 (C017)	C046	[OL] Remote Installation & 45mm Oil Brush Kit
[1 ~ 3] + 10 (C018)	C047	[OL] Remote Installation & 74mm Oil Brush Kit